

Pairing instructions for Purekeys Wireless Keyboard

If you have received a new USB dongle for you keyboard it has to be paired before you can use it.

Instructions:

Check if the batteries are OK and installed the right way by pressing the clean switch on the keyboard. If the green light flashes the batteries are OK and you can press the clean switch again to turn them off.

Install the new USB dongle in a free USB port, place the keyboard close to the computer and press the keys: CONTROL + ALT + P all three together. The green pair light on the keyboard will flash for a few seconds and the keyboard should be ready for use.

If pairing fails you can try another USB port on the computer or check the support section on www.purekeys.com